



CHALK PAINT® WAX

for painted furniture

HEALTH & SAFETY

Keep out of reach of children. Dispose of contents/container in accordance with national regulations.

STORAGE

Always store in a cool and dry place. Ensure lid is tightly sealed after use.



Representative samples of CHALK PAINT® WAX by Annie Sloan have been independently certified as 'toy safe' according to European standards (BS EN 71-3:2013).

What is Chalk Paint® Wax?

Use Chalk Paint® Wax to seal and protect furniture and walls painted with Chalk Paint®. This soft wax brings out depth of colour and gives a beautiful matt finish – or can be buffed to a high sheen. Comes in Clear, White, Dark and Black.

Get started

Test on a small area first. Apply a thin coat of Clear Chalk Paint® Wax onto your painted surface, using a lint-free cloth or Annie Sloan Wax Brush. Work in small areas at a time, 'pushing' the wax into the paint. Remove any excess with Clear Wax and a clean cloth. White Chalk Paint® Wax can be applied directly onto painted surfaces. Apply Dark or Black Chalk Paint® Wax over wet Clear Wax. Remove any excess with Clear Wax and a clean cloth. Wax every part of your piece at least once. Two to three coats will create a wipeable finish for dining room tables and kitchen cabinets. For a high-shine finish, allow 24 hours before buffing with a clean cloth. Treat your finished piece with extra care while the wax cures – this can take between 5 and 21 days.

Aftercare

To maintain your finish wash with mild soapy water and a soft damp cloth, re-wax if necessary. Chalk Paint® Wax is water repellent so can be used on kitchens, cupboards and table tops. Apply two coats of wax. Not recommended for areas with a lot of water. Not suitable for outdoor use. Wash brushes in hot water and soap immediately after use. Results may vary depending on previous treatment of surface.

